

Ad Mat

SETUP INSTRUCTIONS

USE THIS PRODUCT:

- On a dust-free, flat surface only.
- In dry conditions only.
- For cleaning, use any non-scratching detergent.



- Place graphic between rubber mat and window with textured side of window facing up.

- First insert all corners of the window into the corners of the rubber mat.
- Rubber mat is very flexible making it easy to insert corners.



- Bend side edges of rubber mat down.
- Push down on window and fold rubber mat over the window on all four sides enclosing the window under the rubber frame.

- Inspect the edges of the Mat, insuring that all corners and sides of window are enclosed within the rubber frame.

