

## FlexFloor™ To Go Set Up and Dismantel Instructions

- The optimal use for Flex Floor would be on concrete/hard surface flooring. It is not recommended on carpet. If used on carpet, the Flex Floor will not stay in place or have a smooth look and could result in damage.
- Insure the ground is clear from any major debris like rocks, pieces of paper or any other object that may cause imperfections in the floor.
- Take the Flex Floor out of its case.
- Lay out floor according to the diagram provided. Matching up the floor and pattern together will provide a more seamless appearance. Each piece will be numbered with arrows to tell how the floor should be assembled.
- To improve the performance of the Flex Floor, tape the perimeter of the Flex Floor with clear tape or duct tape prior to applying the double faced tape. This will diminish the risk of tearing the Flex Floor backing. Please note that if the flooring is not installed for a permanent use but in a tradeshow application, warranties on this product will become void.
- Use double faced tape around the perimeter of the Flex Floor to secure it to the substrate.
- Floor is now ready to be used.
- Dismantle: Be careful when pulling up Flex Floor. Try not to tear or stretch the flooring. Inform the installer that the floor should be removed from the ground slowly to minimize the possibility of damage.
- Roll the flooring so that the pattern is facing to the outside of the roll. If rolled with the backing towards the outside, potential damage to the floor could occur.
- Place flooring inside its case and lock the lid down for safe storage.

