


Note: The directions are the same for each shape.

Assemble the Stand




Top
(with light hole)



Bottom
(without hole)

Top
(without connector)




Bottom
(with connector)

1


Assemble pole.

2

Find bottom and top of graphic and pole.




Important:
Verify the graphic is not twisted and that the graphic covers the corners.



3

Insert bottom and lock connector by rotating handle clockwise and pushing handle down.




4

Insert top by sliding tapered end into top of pole and push flush.



-After prolonged periods of storage, the graphic may have wrinkles.
To eliminate the wrinkles leave the stand set-up for several hours or use a steamer.*

*A Micro Steamer option is available.




5

Adjust lean to make vertical.

Helpful Tip: It's easier to make the top connection if the stand is held at waist level rather than if your hands are held up over your head.


INSTRUCTIONS

Connect the Shelf



1

Attach support base.* (Tube without hole)
*Left Slope, Right Slope, and Fountain only



2

Attach shelf. (Tube with hole)



- To avoid damaging the acrylic shelf when disassembling the stand, be sure to detach the shelf from the utility bar before removing the utility bar from the stand.
- Guarantee excludes scratching or breaking of acrylic shelf.
- The higher the shelf is positioned, the more likely it is to touch the side of the graphic.
- To improve the strength of the shelf and base tube tighten the connector clamps.

Shelf Placement*


Left Slope	30" h to 46" h
Right Slope	30" h to 46" h
Fountain	30" h to 46" h
Bow	36" h (not adjustable)

*Shelf and base can connect from either side

Weight Limit


- 12 lbs. max per shelf
- 20 lbs. combined total for multiple shelves

Connect the Stand Off Graphic



1

Attach utility bar to main pole.*
*Can connect from either side



2

Attach stand off graphic to utility bar with Velcro strip.




- Utility bar can be placed anywhere between 20" h and 46" h.
- The lower the stand off graphic is positioned, the closer it will be to the main graphic.




Note: The directions are the same for each shape.

Replacing the Graphic



- 1** Slide old graphic out of groove.
Repeat on top and bottom.




- 2** Insert end of new graphic into the groove and slide into place*.
Repeat on top and bottom.

***Helpful Tips:**

- Place the new graphic in the top groove on the top bar and in the bottom groove on the bottom bar.

- When facing the front of the stand, take the left side of the graphic and insert it into the right side of the stand, sliding it from right to left.



Important:

Verify the graphic is not twisted and that the graphic cover the corners.