


Pirouet Setup Instructions



PIROUET :
The easiest,
most complete
portable kiosk for
any environment!




1. Take frame out of the carry case and set on floor with the electrical wire on the bottom (if pre-wired).



2. Twist frame to the right and pull up.




3. Continue twisting until frame is all the way up to full height.



4. Slide clear and/or opaque side panels into place.



5. Important: Panels go BEHIND the main extrusion channel, not in the groove of the frame.



6. Plug electric cord (if pre-wired) into electric socket to illuminate "down" lights.



7. Frame packs neatly in main part of case. Panels pack in front pocket.